



## Hanhart Stop Watch Magma EC250



1. Reset the watch to 0.00.00:00: Press large red button (A) on top for the numbers to stop running. Then press the A button and the small red (B) button simultaneously. All numbers should show zero.

2. Verify the display is SPLIT/LAP: Press the middle front button (C) until the display shows SPLIT next to the top number and LAP next to the bottom number.

3. Pre-Set Time (time of day in which the watch will be start): Depress the right grey button D and hold (the 1/100 sec digit is blinking) Press A and each successive press of D will subsequently display numbers 1 through 9. Select the desired number and release D. Repeat the above for each digit until it is set at the time of day for starting.



4. Start by pressing button A or shorting the electrical terminals on the top

The time on top is the Time of Day for the last time the Red A button has been depressed.